


INSTRUKCJA MONTAŻU PRL 90/120



1	2	3	4	5	6	7	8	9	10	11	12	13	14
4 szt	26 szt	4 szt	4 szt	16 szt	8 szt ∅ 8	8 szt 3,5x16	14 szt 3,5x30	4 szt	4 szt	4 kpl	8 szt	4szt	1 szt